



Installation Guide For:

SC-Mount-JWR2

2022+ Jeep Wrangler JL Series Sport, Willys Sport, Sport S, Willys, Sport Altitude, Sahara, Rubicon, Unlimited Sport, High Tide, Rubicon 392

1. Remove the spare tire from the vehicle
2. Remove the 2 bolts from the top hinge on the outside of back door.
3. Save the manufacturer's bolts to reinstall if you remove the Jeep antenna bracket. These bolts can not be used for the antenna mount.
4. Attach the Jeep antenna bracket to the top hinge of the back door using the supplied internal tooth washers and bolts place the washers between the mount and bolts.
5. Keep the mount level and tighten the bolts completely.



Pic #1

Antenna and mount included