



Installation Guide For: SC-Mount-JWG 2019+ Jeep Gladiator; Sport; Willys Sport; Sport S; Altitude; Willys

1. Open hood and remove fender bolt closest to windshield on the driver's side (Pic #1)
2. Place bracket with the smaller hole to the inside in the seam between hood and fender, driver's side (Pic #2)
3. Reinstall the bolt and tighten
4. Add your antenna and coax



Pic #1



Pic #2