

Installation Guide For: SC-Mount-F1

2022 and newer F150, F250, F350, F450, F550

1. Open hood & remove the 2 bolts from driver-side fender & from hood hinge. This will require a 10mm socket. (Pic #1)



Pic #1

2. Position stainless-steel bracket over the 2nd bolt hole locations with supplied spacer between the bracket and the fender.

3. Use one of the supplied stainless-steel hex-head bolts with washer to locate the hinge-hole . Tighten the bolt until snug, do not fully tighten. (Pic #2) Note: Factory bolt could be used.



Pic #2

4. Use the other supplied bolt and washer to locate the fender hole through the bracket and spacer. Firmly push the bracket with protective pad against the fender and fully tighten the bolt. (Pic #3)

5. Complete installing the bracket by fully tightening the bolt in the hinge hole.



Pic #3