

1. Remove 1 rear top hinge bolts. (Pic #1)
2. Place the Bronco bracket over the threaded hole where you just removed the bolt. Slide one of the external tooth washers supplied onto the bolt supplied with the bracket kit and then thru the bracket into the threaded hole on the Bronco. Do not tighten yet leave snug. (Pic #2)
3. Remove the other hinge bolt and place the other external tooth washer and bolt thru the bracket and thread into the Bronco hinge. (Pic #3)
4. Line the bracket up so it is level and tighten both bolts. (Pic #3)
5. Add your antenna and coax. (Pic #4)



Pic #1



Pic #2



Pic #3



Pic #4

