



Installation Guide For:
SC-Mount-FER
2018 - 2020 Ford Expedition
2019 – 2024 Ford Ranger

1. Locate and remove bolt on driver's side fender. (Pic #1)
2. Place bracket with step washer facing down over bolt hole. (Pic #2)
3. Re-install bolt and tighten.
4. Install your antenna.



Pic 1



Pic 2